



**Kit Number: 104-1001**

**Application: VW/AUDI 2.0L DOHC FSI/TFSI CAM  
TOWER BOLT**

### **Installation Procedure**

1. Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
2. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
3. Install the camshafts, the camshaft caps and the timing gears (if removed) as described in the factory service manual.
4. Lubricate the threads of the bolts and the washers with ARP Ultra-Torque Fastener Assembly Lubricant.
5. Install the bolt(s) and tighten them hand tight.
6. Following the manufacturer's recommended torque sequence, tighten the bolts to:

**130 in-lbs**

If you have any questions or need additional information  
please contact us at (805) 339-2200

Automotive Racing Products  
1863 Eastman Ave. Ventura, Ca 93003  
[www.arp-bolts.com](http://www.arp-bolts.com)